

EAD Series

Desktop Single-channel Erbium Fiber Amplifiers



Applications

- ▶ Fiber Optic Communications
- ▶ Power Booster for Tunable Sources
- ▶ Photonics Switching
- ▶ Components Testing
- ▶ Laboratory Use

Features

- ▶ 0.5-5 W Output Power
- ▶ Low Noise Figure
- ▶ Low PMD
- ▶ APC, AGC and ACC Controls
- ▶ 1530-1570 nm or 1575-1610 nm Operation Bandwidth

IPG Photonics' EAD Series single-channel C-band (1535-1570 nm) and L-band (1575-1605 nm) Erbium-doped Fiber Amplifiers are conveniently packaged for use in a laboratory environment. Everything is contained in one desktop instrument including the EDFA with your choice from 1-5 W saturated power output. The front panel includes a monitor display, a keyed on/off switch, power control and fiber input/outputs; RS232 and GPIB interface controls are located on the rear panel. These universal devices operate in the temperature range of 0-50°C and require 100/110/200/220V AC (50/60 Hz). IPG's EAD Series can be employed for research and development in fields such as telecommunications, photonics switching, sensorics and product test beds.

Standard EAD-C Erbium Fiber Amplifiers provide amplification of an optical input signal in the 1535-1570 nm region and the EAD-L Amplifiers in the 1575-1605 nm region with bandwidth of 35 nm (FWHM). Typical amplifier input and output are provided by a 1.5 meter, standard SMF-28 optical fiber cable with input/output connectors. Typically, an amplifier has 40 dB input and 30 dB output optical isolation. The EAD Series also offers a linear polarization option with an extinction ratio of >17 dB.

EAD Series

Single-channel Erbium Fiber Amplifiers

Optical Characteristics

	EAD-0.5-C(L)	EAD-1-C(L)	EAD-2-C(L)	EAD-5-C(L)
Mode of Operation ¹	Single-channel			
Polarization ²	Random			
Output Power, W	0.5	1	2	5
Optical Bandwidth, nm				
C-band		1535-1567		1540-1570
L-band		1570-1605		1570-1605
Optical Input Power, dBm	-3 to +3		0 to +3	
Typ. Noise Figure, nm				
C-band	5.5		6.0	
L-band	6.0		6.5	
Output Power Stability (over 8 hours, APC mode), dB	0.1-0.02			
Polarization Depend and Loss (PDL), dB	0.3			
Polarization Mode Dispersion (PMD), ps	0.7			
Input/ Output Optical Isolation, dB		40/30		40/25
¹ WDW (gain flattened) amplifiers available on request		⁴ 1530-1565 & 1575-1610 nm bandwidths available on request		
² Linear polarization available on request		⁵ Amplifiers optimized for lower input power available on request		
³ Higher output powers available on request				

General Characteristics

	Min.	Max.
AC Power Line, V	100	
Chassis Dimensions, mm	341 x 132 x 305	
Operational Temperature Range, °C	0 to +50	
Storage Temperature Range, °C	-30 to +70	
Humidity, %	5	90
Warm-up Time, min		1
Cooling	Forced Air/ Heat Sink	
Input/ Output Termination	1.5m SMF-28 Fiber with FC/APC Connectors	

+1 (508) 373-1100
 telecom.us@ipgphotonics.com

www.ipgphotonics.com/telecom

Legal notices: All product information is believed to be accurate and is subject to change without notice. Information contained herein shall legally bind IPG only if it is specifically incorporated into the terms and conditions of a sales agreement. Some specific combinations of options may not be available. The user assumes all risks and liability whatsoever in connection with use of a product or its application. IPG, IPG Photonics, The Power to Transform and IPG Photonics' logo are trademarks of IPG Photonics Corporation. © 2009-14 IPG Photonics Corporation. All rights reserved.

The Power to Transform®